

FIG.1

FIG.2

OPERATION TABLE

	CLUTCH			BRAKE				owc			SOLENOID		
	C-1	C-2	C-3	B-1	B-2	B-3	B-4	F-1	F-2	F-3	SL1	SL2	SR
Р					٠						×	0	X
REV			0	\bigcirc			0	0			×	0	×
N											×	0	×
1ST	0						0			0	×	0	X
2ND	0				(\bigcirc)	0		0	0		×	0	X
3RD	0		0	(\bigcirc)		•		0			×	0	X
4TH	0	0	•			•					X	0	X
5TH		0	0	0							×	×	0
N-D SHIFT	x-O				x-O					×-O	O-×	O-×	0
(O) INDICATES ENGINE BRAKING									OON				
INDICATES ENGAGEMENT WITHOUT TORQUE TRANSFER INDICATES DISENGAGEMENT									×OFF				

